



## **Gen 2 Pajero Intercooler & Sump Bash Plate Installation Instructions**

Boo's Bash Plates have been designed to be fitted directly onto the original fixing holes and bolts so no adjustment should be necessary.

1. Remove the two 10mm bolts holding the front guard on.
2. Remove the two 8mm centre bolts, the front guard will then come off. Be careful not to let guard fall down.
3. Remove the two 8mm bolts at the rear of the second guard.
4. Replace the two centre bolts with the supplied bolts only turning in a couple of revolutions.
5. Slide the slotted end of the new front guard on the two centre bolts, do not tighten.
6. Screw two front bolts into original holes, again only screw in a few revolutions.
7. Now slide the second guard into the two centre bolts underneath the front guard.
8. Now screw in the two back bolts some jiggling may be required to get these in the correct position.
9. Once all of the bolts are in place they can now be tightened to the recommended torque.
10. It is recommended that all bolts are checked regularly to ensure that they have not come loose.