



## **Gen3 Mitsubishi Montero (2001-2006)**

### **Installation Instructions – Steel - Front Skid Plate (VA-LO-M3-1-3SBP)**

#### **Hardware:**

4x M8x25mm high tensile bolts

4x M8 lock washers

4x M8 flat washers

This skid plate has been designed to mount to the existing factory skid plate locations. No permanent modifications are needed and you may reuse your original hardware if preferred.

1. To remove the factory front skid plate, remove the 4x M8 bolts (2 at the front and 2 at the rear of the skid plate).
2. Assemble 2x M8 bolts with a lock washer, then flat washer, and feed them into the rear mounting locations just a few turns. Then place the rear of the new front skid plate onto these bolts so that it is below the oil pan skid plate which shares these 2 mounting bolts.
3. Assemble the remaining 2x M8 bolts with a lock washer, and then flat washer and affix the front of the skid plate to the front mounting holes loosely.
4. After confirming that the skid plate is the desired position, tighten up all of the bolts.
5. It is recommended that all bolts are checked regularly.