



## **Gen3 Mitsubishi Montero (2001-2006)**

### **Installation Instructions – Steel - Oil Pan Skid Plate (VA-LO-M3-2-3SBP)**

#### **Hardware:**

4x M8x25mm high tensile bolts

4x M8 lock washers

4x M8 flat washers

This skid plate has been designed to mount to the existing factory skid plate locations. No permanent modifications are needed and you may reuse your original hardware if preferred.

1. To remove the factory splash guard, remove the 4x M8 bolts (2 at the front and 2 at the rear of the splash guard).
2. Assemble 2x M8 bolts with a lock washer, then flat washer and feed them into the front mounting locations just a few turns. Then place the front of the new oil pan skid plate onto these bolts so that it is above the front skid plate which shares these 2 mounting bolts.
3. Assemble the remaining 2x M8 bolts with a lock washer, and then flat washer and affix the rear of the oil pan skid plate to the rear chassis mounts loosely.
4. After confirming that the skid plate is the desired position, tighten up all of the bolts.
5. It is recommended that all bolts are checked regularly.