



Gen3 Mitsubishi Montero (2001-2006)

Installation Instructions – Aluminium Transmission Skid Plate (VA-LO-M3-3B-6A)

Hardware:

2x M8x35mm high tensile bolts

4x M8 lock washers

2x M8 nyloc nuts

2x M8x25mm high tensile bolts

4x M8 flat washers

2x clamp plates

This skid plate has been designed to mount to the vehicle with no permanent modifications required.

1. Assemble the 2x M8x25mm bolts with a lock washer, then flat washer. Lift the skid plate into position and use the bolts to loosely attach the front of the transmission skid plate to the 2 mounting brackets at the rear of the engine crossmember.
2. Assemble the 2x M8x35mm bolts with a lock washer, and then flat washer and feed them through one of the two holes at the rear of the skid plate. Then place a clamp plate over the top of the bolt so that it pinches the rear lip of the transmission crossmember and then secure loosely with a nyloc nut. Repeat on the other side.
3. After confirming that the skid plate is in the desired position, tighten up all of the bolts.
4. It is recommended that all bolts are checked regularly.

